

ELIMINATE

Worn thru ducts & expensive repairs.

REDUCE

Down time & soil build up in ducts.



NEW FOR 2005

PolyLast™ Duct Liners



Amadas Peanut Combine Kit Chart

9097 Peanut Combines	Serial #'s	Poly Tech Kit #
9097	A28002-A28556	PCAK001
9097	A29001-A29372	PCAK001
9297 Peanut Combines		
9297	A29378-A30324	PCAK002
9297	A30325-A30478	PCAK002
9297	A31001-A31357	PCAK002
9297	Beginning A31189	PCAK002
9297	A32022-A32701	PCAK002
9597 Peanut Combines		
9597	A33110-A33694	PCAK003
9597	A34136-A34985	PCAK003
9797 Peanut Combines		
9797	A35000-A35784	PCAK003
9797	A36089-A36108	PCAK003
9797T	A35549-A35726	PCAK003
9897 Peanut Combines		
9897	A36000-A36878	PCAK003
9897T	A36672-A36790	PCAK004
9997 Peanut Combines		
9997A	370248-370258	PCAK004
9997B	370265-370265	PCAK004
9997E	370243-370874	PCAK003
9997F	Beginning 380000	PCAK003
9997F	Beginning 420000	PCAK003
9997T	370253-370312	PCAK004
2100 Peanut Combines		
M2100D/M9997T	Beginning 380000	PCAK004
M2100D/M9997T	Beginning 380000	PCAK004
M2100A/M9997A	Beginning 380000	PCAK004
M2100D/M2100T	Beginning 410000	PCAK004
M2100D/M2100T	Beginning 420000	PCAK004
M2100D/M2100T	Beginning 430000	PCAK004

500 & 8557 Series Peanut Combines: Not Available



Poly Tech Industries, Inc. / P.O. Drawer 349 / Monticello, GA 31064
800.542.7659 / polyskid.com